



SWH-G02-B*-A* /D** /R*** -10**

Northman Fluid Power, 739 Kimberly Dr., Carol Stream, IL 60188

Ph: (630) 588-8488 Fx: (630) 588-8487 www.northmanfp.com

Northman
Fluid Power

Built to Endure

SWH-G02-B*-A* /D** /R***-10**

Parts List

Item No.	Qty	P/N	Price List P/N & Description
1	1	-	Valve Body
2	1	SPG-02B* (* = Spool Code)	SP-G02-C* Standard Spool
		SPG-02B*M (* = Spool Code)	SP-G02-C*-M Shockless Spool
3	1	TUB-EG02AC	Tube G02-AC Armature Tube, AC
		TUB-EG02DC	Tube G02-DC Armature Tube, DC and Rectified AC
		Tube G02-AC-PB	Tube G02-AC-PB Armature Tube, AC, Ext.Push Button
		Tube G02-DC-PB	Tube G02-DC-PB Armature Tube, DC, Ext.Push Button
4	1	NWH-G02A***10 (***) = Voltage)	NWH-G02-A***-10 Solenoid Coil, AC
		NWH-G02D**10 (** = Voltage)	NWH-G02-D**-10 Solenoid Coil, DC
		NWH-G02R***10 (***) = Voltage)	NWH-G02-R***-10 Solenoid Coil, AC Rectified
5	1	G02 Coil Nut	G02 Coil Nut
6	1	G02 Push Pin for Armature Tube	G02 Push Pin for Armature Tube
7	2	G02 Black Spring for AC	G02 Black Spring for AC
		G02 Black Spring for DC/RF	G02 Black Spring for DC/RF (Ex. C6 Spool)
		G02 Silver Spring for DC/RF	G02 Silver Spring for DC & RF, C6 Spool
8	2	G02 Spring Washer	G02 Spring Washer
9	2	G02 Spool Washer	G02 Spool Washer
10	1	G02 Standard Bolt Kit [(4) bolts]	G02 Standard Bolt Kit [(4) bolts]
11	1	G02 Junction Box (Straight)	G02 Junction Box (Straight)
		G02 Junction Box (Diagonal)	G02 Junction Box (Diagonal)
12	1	912-63100	912-63100 G02 AC Terminal (Straight)
		912-63150	912-63150 G02 AC Terminal (Diagonal)
		912-63200	912-63200 G02 DC Terminal (Straight)
		912-63250	912-63250 G02 DC Terminal (Diagonal)
		912-63300	912-63300 G02 Rectified Terminal (Straight)
		912-63350	912-63350 G02 Rectified Terminal (Diagonal)
13	1	G02 Nameplate	Nameplate [Comes with (4) screws, Item 14]
14	4	-	Nameplate Screws
15	1	G02 Dust Cover for Junction Box	G02 Dust Cover for Junction Box
16	4	-	Terminal Block Screw
17-19, 22	1	SKSWHG02B	SWH-G02 Buna Seal Kit
		SKSWHG02V	SWH-G02 Viton Seal Kit
20	4	-	Spring Pin
21	2	-	Junction Box Dust Plug
23	4	-	Junction Box Screw
24	1	G02 Bottom Valve Cover	G02 Port Dust Cover (Not Shown)
25	1	-	Hex Plug
26	1	-	Spring Support

Note: Items with Part Numbers are available for customer purchase.

Northman Fluid Power, 739 Kimberly Dr., Carol Stream, IL 60188
Ph: (630) 588-8488 Fx: (630) 588-8487 www.northmanfp.com